



ADDING A NEW LIGHT(S) TO AN EXISTING LINKED NETWORK *(but you can't find the Original Master Light)*

For ALL Radar 360° + LINKABLE models

Radar 360° LINKABLE is so smart you can add new Radar 360° LINKABLE lights to the network at any time. Ideally you can easily identify your original Master Light. However if this is no longer possible don't worry. With just a few extra steps you can still link your new lights to the existing network.

1. Decide where you would like to add the new light.
2. Find the nearest existing Radar 360° LINKABLE light. This will become the new Master light. You will not need to find your Original Master.
3. Turn all existing Linked lights to off.
4. You will now need to unlink your existing linked Radar 360° lights from the linked network. Please follow the instruction sheet "**Unlinking Your Radar 360° Lights**"
5. Then simply follow the instruction document for "**2 Lights** (if you want to add 1 new light)" or "**3 or More Lights** (if you want to add 2 or more new light)" depending on how many you have new lights you wish to link to the existing network.
6. When completed, turn ALL linked lights to the desired Light Setting.

When the linking process is completed, the Radar 360 Linkable° lights create a new chain of lights which includes the old lights and the new lights.

If the link is not working as expected, simply reset your lights to factory setting by following the "Unlinking your Radar 360 Light" Instructions and then start again.