



UNLINKING YOUR RADAR 360° LIGHTS

For Preston+, Persist+ & Lexington+ models

Radar 360° lights can be linked to other Radar 360° Linkable lights OR used unlinked on a standalone basis.


Standalone Basis

If never previously linked simply charge your light and set to the desired Light Settings below.

Radar 360° is super smart and also has 2 light settings on the same switch that is used to link the lights. Take note of the markings above and to the right of the switch.

H Goes from NO light to FULL brightness when triggered. After about 30 seconds lights turns off.

L-H Always remains on LOW AMBIENT when the sun goes down but goes to FULL brightness when triggered. After about 30 seconds lights turns back to LOW AMBIENT.



Set each light according to your light preferences. Lights will last longer when on **H** setting.

Unlinking your Radar 360° Lights

1. To remove a light from the linked network for use as standalone, switch the light you wish to remove to the “**S**” position.
2. Press and hold the **LINK** button for more than 10 seconds.
3. Once the light changes from flashing to solid, the linked light has been unlinked to the network.



Other linked lights will not be affected.

4. Release the **LINK** button.
5. Now turn **OFF** and back on to the desired Light setting.



You are now free to relocate your light to another unlinked location.